


Quick Installation Guide

PCI/PCI Express Network Adapter

MODEL NO. TG-3269/ TG-3468/ TF-3200/ TF-3239DL


Package Contents



System Support

- Windows XP • Windows 7 • Windows Vista • Linux
- Windows 2000 • Windows 2003 (TF-3200 only)

1 Hardware Connection



You may see the **Found New Hardware Wizard** when the adapter is plugged. Please click 'Cancel'.

For Windows XP



Steps:


1. Turn off your computer and unplug the power cord from the computer.
2. Open the case. Locate an available PCI/PCI Express slot and remove its slot cover. Keep the screw.
3. Insert the adapter into the PCI/PCI Express slot as shown above.
4. Secure the adapter with the screw removed in Step 2.
5. Close the case and insert the power cord back into the computer.
6. Turn on your computer.

2 Software Installation

(Please select the instructions according to your operating system. Here takes TG-3269 for example to illustrate the installation procedures.)

For Windows XP


- 1 Insert the TP-LINK Resource CD into the CD-ROM drive.



- 2 Right-click **My Computer**, and then click **Manage**.




- 3 Open **Device Manager**. Find your network adapter and right-click it; then click **Update Driver ...**




For TF-3200, you need to refer to **Appendix: Troubleshooting -T2** for the installation of this step.

- 4 Select **Install from a list or specific location[Advanced]**, and click **Next**.



- 5 Select **Don't Search. I will choose the driver to install**, and click **Next**.



- 6 Click **Have Disk ...**.



- 7 Click **Browse ...**




- 8 Find the right product model and operation system in the resource CD directory, choose the .inf file, and then click **Open**.




- 9 Click **OK**.



- 10 Click **Next**.



- 11 Click **Continue Anyway**.




- 12 Click **Finish** to complete the installation.




For Windows 7


1 Insert the TP-LINK Resource CD into the CD-ROM drive.



2 Right-click **Computer**, and then click **Manage**.




3 Open **Device Manager**. Find the network adapter you've just installed under **Network Adapter** and right-click it; then click **Update Driver Software...**.




NOTE: For TF-3200, you need to refer to **Appendix: Troubleshooting -T2** for the installation of this step.

5 Select **Let me pick from a list of device drivers on my computer**.

6 Click **Have Disk...**




9 Click **OK**.




10 Click **Yes**.



7 Click **Browse....**



11 Click **Next**.




15 Click **Yes** to restart the computer so that the installation will take effect.




13 Wait a few seconds.




14 Click **Close** to finish the installation.




4 Select **Browse my computer for driver software**.



8 Find the right product model and operation system in the resource CD directory, choose the **.inf** file, and then click **Open**.



12 Click **Install this driver software anyway** to continue the installation.




Appendix: Troubleshooting

T1. What should I do if PC cannot find the new hardware?

Check to see if the network adapter is inserted in the PCI/ PCI Express slot properly; otherwise, please reinsert the adapter. If the problem remains, please try to change another PCI/ PCI Express slot.

T2. What should I do if PC cannot identify the new hardware?

If you couldn't find your newly-installed network adapter by going to "**(My) Computer > Manager > Device Manager > Network Adapter >...**"; please go to "**(My) Computer > Manager > Device Manager > Other devices > Ethernet Controller**", and then follow rest of the software installation steps to update driver.



* If you need more information about the product, please refer to the **User Guide** on the resource CD.

Technical Support

- For more troubleshooting help, go to www.tp-link.com/support/faq.asp
- To download the latest Firmware, Driver, Utility and User Guide, go to www.tp-link.com/support/download.asp
- For all other technical support, please contact us by using the following details:

Global

Tel: +86 755 26504400
E-mail: support@tp-link.com
Service time: 24hrs, 7days a week

Singapore

Tel: +65 62840493
E-mail: support.sg@tp-link.com
Service time: 24hrs, 7days a week

UK

Tel: +44 (0) 845 147 0017
E-mail: support.uk@tp-link.com
Service time: 24hrs, 7days a week

Malaysia

Tel: 1300 88 875465 (1300 88TPLINK)
E-mail: support.my@tp-link.com
Service time: 24 hrs a day, 7days a week

USA/Canada

Toll Free: +1 866 225 8139
E-mail: support.usa@tp-link.com
Service time: 24hrs,7days a week

Turkey

Tel: 444 19 25 (Turkish Service)
E-mail: support.tr@tp-link.com
Service time: 9:00 AM to 6:00 PM, 7days a week

Brazilian(Portuguese Service)

Toll Free: 0800-770-4337
E-mail: supoerte.br@tp-link.com
Service time: Monday to Saturday 08:00 AM to 08:00 PM

Switzerland

Tel: +41 (0)848 800998 (German service)
E-mail: support.ch@tp-link.com
Fee: 4-8 Rp/min, depending on rate of different time
Service time: Monday to Friday 9:00 AM to 6:00 PM. GMT+1 or GMT+2 (Daylight Saving Time in Germany)
* Except bank holidays in Hesse

Italy

Tel: +39 02 66987799
E-mail: support.it@tp-link.com
Service time: 9:00 AM to 6:00 PM, from Monday to Friday

Ukrainian

Tel: +380 (44) 590-51-14
E-mail: support.ua@tp-link.com
Service time: Monday to Friday 14:00 PM to 22:00 PM

Australia & New Zealand

Tel: AU 1300 87 5465 NZ 0800 87 5465 E-mail: support@tp-link.com Service time: Monday to Friday 9:00 -12:00 ; 13:00 -18:00 *Except public holidays

Russian Federation

Tel: 8 (495) 223-55-60 8 (800) 250-55-60 (toll-free call from any RF region) E-mail: support.ru@tp-link.com Service time: From 10:00 to 18:00 (Moscow time)* Except weekends and holidays in Russian Federation

Germany / Austria

Tel: +49 1805 875465 (German Service) / +49 1805 TPLINK E-mail: support.de@tp-link.com Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone. Service Time: Monday to Friday 9:00 AM to 6:00 PM. GMT+1 or GMT+2 (Daylight Saving Time in Germany)* Except bank holidays in Hesse